



Sorting and Feeding of Xalatan Bottles



Xalatan Bottle
Height 56 mm

Feeding System

Reference-No. 176



Description:

Sector

Pharmaceutical Industry.

Workpiece

Filled and closed bottles

Performance Requirements

A positionally correct feed.

Discharging Position

Hanging on the bottle opening with the bottle contour oriented lengthwise.

Operation Description

The bottles are loaded into the bowl. During the sorting the bottles are grasped and hung on their openings and passed to a linear track.



During the delivery the rectangular bottle contour is turned lengthwise and passed to the linear track. The bottles leave the linear track flowing freely.

Feeding rate

60 bottles per minute.

Execution

Pharmaceutical design

- Bowl thoroughly welded and finely buffed.
- An exhaust fan integrated into the hood which discharged exit air out of the hood.
- Sound proof cover in inox brushed



Technical Contact: Mr Ken Cotterill



RNA Automation Ltd

Hayward Industrial Park, Tameside Drive, Castle Bromwich, Birmingham, B35 7AG

Tel: +44 (0)121 749 2566 Fax: +44 (0)121 749 6217

Email: sales@rna-uk.com Web: www.rna-uk.com